


INSTALLATION:

Razor wire must be installed to a fence or structure at a minimum height of 2 metres above ground level and should not be used either as a complete barrier where there is public access, or in any place where accidental contact is likely by any person



INSTALLATION OPTIONS

WARNINGS:

Warning signs must be clearly displayed on all structures to which Razor wire is Affixed stating:

DANGER – PROPERTY PROTECTED BY RAZOR WIRE DO NOT TOUCH OR CLIMB

It is recommended that warning signs be affixed at 7.5m intervals along the fence-line



We advise that failure to install these products within the listed guidelines, or to handle them with due care, could result in serious injury.

No responsibility for damage or injury caused by misuse or miss handling of these products can be accepted by Wire Works NZ Ltd or the manufacturers

Razor wire should only be installed by those with suitable training and using appropriate Personal Protection Equipment

